





Ruino





Ruino





```
RSR50-X-84#show version slots
```


Module	Status	Dev	Slot	MaxPorts	Configured-Module	Online-Module
1	not present	1	PM1	1	RSR50-X-CHT	RSR50-X-CHT
2	alarm	1	MP1	1	RSR50-X-CHT	RSR50-X-CHT
100	running	1	SPU	0	RSR50-X-SPU100	RSR50-X-SPU100
1000	none	1	1/1	0		

```

RSR50-X-84#sh version slots
Dev Slot MaxPorts Configured-Module online-Module Status
-----
1 - 1 1 RSR50-X-CH1 RSR50-X-CH1 master
  - 2 1 RSR50-X-CH1 RSR50-X-CH1 slave
... 1 10 RSR50-X-SPU100 RSR50-X-SPU100 running
  1 1/1 2 HEDC-3AE installed
  1 1/2 0 none
  1 1/3 0 none
  1 1/4 0 none
  1 2/1 0 none
  1 2/2 0 none
  1 3/1 0 none
  1 3/2 0 none
  1 4/1 0 none
  1 4/2 0 none
  1 5/1 0 none
  1 5/2 10 HNM-8GT2SFP HNM-8GT2SFP running
RSR50-X-84#
RSR50-X-84#

```

Ruino







```
RSR50-X-84#show memory
System Memory Statistic:
Free pages: 369180
watermarks :_min 3360..._lower 4947..._low 6525..._high 8103..._...
Free memory: 2472630k      System Total memory: 4096M, 00000000
Used Rate : 29%
RSR50-X-84#
```

```
RSR50-X-84#sh ip fpm statistics
Flow table capacity: 57344
FRQ capacity: 1024
Flow number: 1
Nat-flow number: 0
User number: 1
Defragment context number: 0
Defragment packet number: 0
Event count: 30

s/100-1/0 : 250150-250100
Flow table capacity: 1441792
FRQ capacity: 4096
Flow number: 0
Nat-flow number: 0
User number: 0
Defragment context number: 0
Defragment packet number: 0
Event count: 30

RSR50-X-84#
RSR50-X-84#
```





Ruino





Ruino





Ruino







Ruino





Ruino







Ruino







Ruino



